

CPU/UPS CART

PART NUMBER: NK-CPU CART

Installation Procedures



741 N Main Street ▪ Orange, California 92868 ▪ Phone 714-288-1848 ▪ Fax 714-288-1838
www.intelligentpowersolutions.com

Tools Required:

- Scissors
- 7/16" wrench (only required if bolting two carts together)

The NK CPU Cart is shipped with all components necessary to mount the NK CPU or UPS and includes the following:



<u>QTY.</u>	<u>PART</u>
1	CPU/UPS Cart
2	Velcro Straps
4	Anti-skid pads

Figure 1

Step 1

Route the two Velcro straps through the mounting holes as shown Figure 2 & 3. (Determine which holes to use by placing the unit on the cart and using the holes closest to the unit.) Place the CPU or UPS in the center of the cart, between the two sides.



Figure 2



Figure 3

Step 2

If your CPU/UPS does not have non-skid feet, four anti-skid pads have been provided. Position the pads on the cart so the unit will rest on the pads when it is placed on the cart.

(Figure 4)



Figure 4

Step 3

Place the equipment on the cart as shown in Figure 5.



Figure 5

Step 4

Pull the straps to the top of the unit as shown in Figure 6



Figure 6

Step 5

Fold one end of the strap across unit. (Figure 7) Fold other end over tightly. Repeat for the other strap. (Figure 8)



Figure 7



Figure 8

Step 6

Cut the straps to desired length as shown in Figure 9. **Note: For best results, heat cut ends to prevent fraying.**



Figure 9

Step 7

Each cart comes with a 7/16 mounting bolt attached. (Figure 10) If you would like to attach two carts, use the bolts off of each unit and attach the two carts through the same holes the bolts were removed from. (Figure 11)



Figure 10



Figure 11

Once the carts have been connected follow the steps provided to attach your unit.

**For Sales and Service Contact:
INTELLIGENT POWER SOLUTIONS, INC.**

741 N MAIN STREET
ORANGE, CA 92868
714-288-1848
Fax 714-288-1838